




4 BASIC OPERATIONS

4.1 Screen Lock/Unlock

The screen dims 30 seconds after no operation, and then turns dark in 10 seconds.

To lock or unlock the screen, hold  and  simultaneously for 1.5 seconds.

4.2 Unit ON/OFF

Select an appliance (icon 3, 6, or 10) in Page A, and press  to turn ON/OFF the selected appliance.

Appliance color on the wired controller	Appliance status
Dark gray	OFF
Light orange	ON(heating mode)
Light blue	ON(cooling mode)

4.3 Temperature Settings

Select an appliance, and press  and  to adjust the set temperature.

- Set temperature adjustment is feasible regardless of the appliance status.